

Setup Guide

Thank you for choosing a COBY MP3 player!



~This guide will cover how to transfer your music CD's into your COBY MP3 player using Windows Media Player 11

~This guide will also provide common troubleshooting solutions for your COBY MP3 player.

Requirements

Windows Media Player 11 (WMP11)

The directions in this guide are given for Windows Media Player 11 (WMP11)


If your computer does not have Windows Media Player installed, please download the latest version of Windows Media Player (WMP) from Microsoft's website

www.microsoft.com/windows/windowsmedia/player/download/download.aspx

AUDIO TRANSFER – Getting Started

Transfer your Music CD's into your COBY MP3 player

1) Launch the WMP11 program.



2) Put an audio CD into the CD-ROM drive of your computer.

- ★ If your computer has an internet connection, WMP will automatically retrieve and display the album information.

Click the “**Rip**” tab and select which “Title” to rip.
To rip the entire album, check all of the check




The screenshot shows the Windows Media Player interface with the 'Rip' tab selected. The album 'Coming Home (D:)' by Lionel Richie is displayed. The album cover shows Lionel Richie. The album is rated with 4 stars. The track list is as follows:

Album	Title	Length	Rip Status	Contributing Artist	Composer
Coming Home (D:)	1 I Call It Love	3:19	Stopped	Lionel Richie	Herman...
Lionel Richie	2 Sweet Vacation	3:54		Lionel Richie	Lionel Ri...
Soul and R&B	3 Why	4:01		Lionel Richie	Chuckii ...
2006	4 What You Are	4:12		Lionel Richie	Jermain...
☆☆☆☆☆	5 Up All Night	3:36		Lionel Richie	Chuckii ...
	6 I'm Coming Home	4:18		Lionel Richie	Chuckii ...
	7 All Around the World	3:34		Lionel Richie	Lionel Ri...
	8 Out of My Head	3:15		Lionel Richie	Lionel Ri...
	9 Reason to Believe	4:46		Lionel Richie	Dallas A...
	10 Stand Down	4:02		Lionel Richie	Dallas A...
	11 I Love You	4:12		Lionel Richie	Lionel Ri...

3) Set the Rip Options (optional).

Click the “**Rip**” button to set the Rip options. The recommended Rip settings are:

- ✧ Select “Format > mp3”
- ✧ Select “Bit Rate > 128 Kbps”
- ✧ Select “More Options” to change the directory to which WMP saves your ripped ✧ music les. WMP will save your music to your “My Documents > My Music” folder by default.




4) Start ripping the CD.

Click the “**Rip**” button and select “Rip” to start converting the audio CD to MP3/WMA



The ripping process will take a few minutes to complete. WMP will save the converted music files in your “My Documents > My Music” folder by default.



Transfer MP3/WMA Files to Your COBY Player




Once you have MP3 or WMA digital music files on your computer, transfer them to your COBY player in order to listen to music anywhere.

Use WMP11 to transfer (sync) music from your computer to your COBY MP3 player.


1) Launch the WMP11 program.

2) Connect your COBY player to a USB port on the computer.

✦ WMP11 will detect your COBY player automatically.



3) Browse your music library to choose songs to sync.



4) Select songs to sync to your COBY player.



5) Disconnect your COBY player from the computer.

Once the sync process is complete, unplug your player from the USB port of the computer. Now you're ready to listen to music on your COBY player.

The screenshot shows the iTunes application window with the 'Sync' tab selected. The main pane displays 'Sync Results' for the device 'MP-C951'. A table lists the files synchronized to the device, all marked as 'Synchronized to device' and 'Files You Added'. The sidebar on the left shows the device 'MP-C951' selected under the 'Library' section. The right sidebar shows the device name 'MP-C951', its capacity '7.4 GB', and a progress bar indicating '6 GB remaining'. Below the progress bar, a message states 'You can now disconnect 'MP-C951'.' and a 'Start Sync' button is visible.

Title	Status	Playlist
Files You Added		
Many Rivers To Cross	Synchronized to device	Files You Added
Homeland and Hip Hop	Synchronized to device	Files You Added
Damaged Goods	Synchronized to device	Files You Added
Two-Headed Boy	Synchronized to device	Files You Added
05 - 53rd & 3rd	Synchronized to device	Files You Added
The Illest (ft. Jean Gr...	Synchronized to device	Files You Added
Hater's Anthem	Synchronized to device	Files You Added
Hustler's Ambition	Synchronized to device	Files You Added
Holla (Ft. Dr.Dre)	Synchronized to device	Files You Added
Mos Def & Talib Kweli...	Synchronized to device	Files You Added
Revolution 909	Synchronized to device	Files You Added
Daft Punk Is Playing A...	Synchronized to device	Files You Added

VIDEO TRANSFER – Getting Started

Converting your VIDEO files and transferring it into your player.

Install the Conversion Utility

1. Insert the Driver CD
2. Copy the “Video Converting” folder.
3. Paste the “Video Converting” folder on your desktop.

Run the Conversion Utility

1. On your desktop, open the “Video Converting” folder.
2. Double click on the “video2smv.exe” file.
3. The program will initialize.

Converting Video (see diagram below)

- 1.a** Find and Select the video files to convert in the INPUT Video field.
- 1.b** Select the directory where you want to save the converted file.
- 1.c** Start the conversion process

When the conversion is completed, copy and paste or drag and drop the converted files to your MP3 player “MVIDEO” folder.

Done!!

Files

Input Video:

Select Input Video File

1.a

...

Output File:

1.b

...

Settings

Quality Level

Medium (128MByte/hr)

▼

Details

Dimension:

128x112

▼

Selection

☒ Start

☐ End



1.c

Convert

Quit

Common Troubleshooting

Problems

Possible Solutions

No Power

- *Ensure that the "HOLD" button is turned off.
- *The Battery level may be too low. Charge the unit.
- *Reset the unit by inserting a pin on the back of the unit "Reset" hole.

Music does NOT Play or Freezes

- *The file(s) are corrupted or damaged.
- *Unsupported file format (ACC, WAV, M4A...Etc.)
- * DRM issues (If the file was obtain from a subscription service, be sure to transfer your DRM license to the MP3 player.

No Sound after file transfer

- *Ensure that the original file plays on your computer. If not, then you will need to obtain the codec for that file.
- *Unsupported format.

Video Conversion Error

- *Ensure that the original file plays on your computer. If not, then you will need to obtain the codec for that file.
- *Unsupported format.

Video Issues

- *Make sure that you are using the correct output frame size and the correct output frame rate.
- *For the best output frame size, set the MTV Video Converter to 160X128 or 160X112 @ 15fps (sports Video).

Computer does NOT recognized the MP3 player

- *Check the connections.
- *Switch USB ports or DO NOT use a USB extension cable.

If you are still having difficulty with your MP3 player, please contact Customer Care, Hours of operation, Monday-Friday 8:00 AM – 8:30:00 PM EST, Saturday and Sunday 9:00 AM – 5:30 PM EST. You can also reach us online at

customerservice@cobyusa.com or techsupport@cobyusa.com

1-800-727- 3592

Setup Guide

Thank you for choosing a COBY MP3 player!



~This guide will cover how to transfer your music CD's into your COBY MP3 player using Windows Media Player 11

~This guide will also provide common troubleshooting solutions for your COBY MP3 player.

Requirements

Windows Media Player 11 (WMP11)

The directions in this guide are given for Windows Media Player 11 (WMP11)


If your computer does not have Windows Media Player installed, please download the latest version of Windows Media Player (WMP) from Microsoft's website

www.microsoft.com/windows/windowsmedia/player/download/download.aspx

AUDIO TRANSFER – Getting Started

Transfer your Music CD's into your COBY MP3 player

1) Launch the WMP11 program.



2) Put an audio CD into the CD-ROM drive of your computer.

- ★ If your computer has an internet connection, WMP will automatically retrieve and display the album information.

Click the “**Rip**” tab and select which “Title” to rip.
To rip the entire album, check all of the check




The screenshot shows the Windows Media Player interface with the 'Rip' tab selected. The album 'Coming Home (D:)' by Lionel Richie is displayed. The album cover shows Lionel Richie. The album is rated with 4 stars. The track list is as follows:

Album	Title	Length	Rip Status	Contributing Artist	Composer
Coming Home (D:)	1 I Call It Love	3:19	Stopped	Lionel Richie	Herman...
Lionel Richie	2 Sweet Vacation	3:54		Lionel Richie	Lionel Ri...
Soul and R&B	3 Why	4:01		Lionel Richie	Chuckii ...
2006	4 What You Are	4:12		Lionel Richie	Jermain...
☆☆☆☆☆	5 Up All Night	3:36		Lionel Richie	Chuckii ...
	6 I'm Coming Home	4:18		Lionel Richie	Chuckii ...
	7 All Around the World	3:34		Lionel Richie	Lionel Ri...
	8 Out of My Head	3:15		Lionel Richie	Lionel Ri...
	9 Reason to Believe	4:46		Lionel Richie	Dallas A...
	10 Stand Down	4:02		Lionel Richie	Dallas A...
	11 I Love You	4:12		Lionel Richie	Lionel Ri...

3) Set the Rip Options (optional).

Click the “**Rip**” button to set the Rip options. The recommended Rip settings are:

- ✧ Select “Format > mp3”
- ✧ Select “Bit Rate > 128 Kbps”
- ✧ Select “More Options” to change the directory to which WMP saves your ripped ✧ music les. WMP will save your music to your “My Documents > My Music” folder by default.




4) Start ripping the CD.

Click the “**Rip**” button and select “Rip” to start converting the audio CD to MP3/WMA



The ripping process will take a few minutes to complete. WMP will save the converted music files in your “My Documents > My Music” folder by default.



Transfer MP3/WMA Files to Your COBY Player




Once you have MP3 or WMA digital music files on your computer, transfer them to your COBY player in order to listen to music anywhere.

Use WMP11 to transfer (sync) music from your computer to your COBY MP3 player.


1) Launch the WMP11 program.

2) Connect your COBY player to a USB port on the computer.

✦ WMP11 will detect your COBY player automatically.



3) Browse your music library to choose songs to sync.



4) Select songs to sync to your COBY player.



5) Disconnect your COBY player from the computer.

Once the sync process is complete, unplug your player from the USB port of the computer. Now you're ready to listen to music on your COBY player.

The screenshot shows the iTunes application window with the 'Sync' tab selected. The main pane displays 'Sync Results' for the device 'MP-C951'. A table lists the files synchronized to the device, all with the status 'Synchronized to device' and the playlist 'Files You Added'. The sidebar on the left shows the device 'MP-C951' selected under the 'Library' section. The right sidebar shows the device name 'MP-C951', its capacity '7.4 GB', and a progress bar indicating '6 GB remaining'. Below the progress bar, a message states 'You can now disconnect 'MP-C951'.' and a 'Start Sync' button is visible.

Title	Status	Playlist
Files You Added		
Many Rivers To Cross	Synchronized to device	Files You Added
Homeland and Hip Hop	Synchronized to device	Files You Added
Damaged Goods	Synchronized to device	Files You Added
Two-Headed Boy	Synchronized to device	Files You Added
05 - 53rd & 3rd	Synchronized to device	Files You Added
The Illest (ft. Jean Gr...	Synchronized to device	Files You Added
Hater's Anthem	Synchronized to device	Files You Added
Hustler's Ambition	Synchronized to device	Files You Added
Holla (Ft. Dr.Dre)	Synchronized to device	Files You Added
Mos Def & Talib Kweli...	Synchronized to device	Files You Added
Revolution 909	Synchronized to device	Files You Added
Daft Punk Is Playing A...	Synchronized to device	Files You Added

VIDEO TRANSFER – Getting Started

Converting your VIDEO files and transferring it into your player.

Install the Conversion Utility

1. Insert the Driver CD
2. Copy the “Video Converting” folder.
3. Paste the “Video Converting” folder on your desktop.

Run the Conversion Utility

1. On your desktop, open the “Video Converting” folder.
2. Double click on the “video2smv.exe” file.
3. The program will initialize.

Converting Video (see diagram below)

- 1.a** Find and Select the video files to convert in the INPUT Video field.
- 1.b** Select the directory where you want to save the converted file.
- 1.c** Start the conversion process

When the conversion is completed, copy and paste or drag and drop the converted files to your MP3 player “MVIDEO” folder.

Done!!

Files

Input Video:

Select Input Video File

1.a

...

Output File:

1.b

...

Settings

Quality Level

Medium (128MByte/hr)

▼

Details

Dimension:

128x112

▼

Selection

☒ Start

☐ End



1.c

Convert

Quit

Common Troubleshooting

Problems

Possible Solutions

No Power

- *Ensure that the "HOLD" button is turned off.
- *The Battery level may be too low. Charge the unit.
- *Reset the unit by inserting a pin on the back of the unit "Reset" hole.

Music does NOT Play or Freezes

- *The file(s) are corrupted or damaged.
- *Unsupported file format (ACC, WAV, M4A...Etc.)
- * DRM issues (If the file was obtain from a subscription service, be sure to transfer your DRM license to the MP3 player.

No Sound after file transfer

- *Ensure that the original file plays on your computer. If not, then you will need to obtain the codec for that file.
- *Unsupported format.

Video Conversion Error

- *Ensure that the original file plays on your computer. If not, then you will need to obtain the codec for that file.
- *Unsupported format.

Video Issues

- *Make sure that you are using the correct setting for the Quality Level and Dimension.
- *For the best video setting, set the Quality Level to High and the Dimension to 128X112

Computer does NOT recognized the MP3 player

- *Check the connections.
- *Switch USB ports or DO NOT use a USB extension cable.

If you are still having difficulty with your MP3 player, please contact Customer Care, Hours of operation, Monday-Friday 8:00 AM – 8:30:00 PM EST, Saturday and Sunday 9:00 AM – 5:30 PM EST. You can also reach us online at

customerservice@cobyusa.com or techsupport@cobyusa.com

1-800-727- 3592